

FIT EVAL

CREATING A FIT EVALUATION WHEN THERE IS A FACTORY CHANGE

When there is a factory change after a PP sample has already been approved, a new Fit Evaluation page is needed. The Fit Eval for the new factory will be generated from the same POM page as the original Factory.

The new Fit Eval page MUST contain the following:

1. All required fields MUST be filled out on the Fit Eval page, including Agent, Vendor, and Factory. See “REQUIRED FIELDS” list on separate page for additional field requirements.

NOTE: Agent, vendor, and factory MUST be filled out BEFORE saving to ensure access after closing the fit eval.

The screenshot shows the 'Fit Evaluation' form with several fields highlighted by red boxes to indicate they are required:

- Evaluation Information:** Agent (LI & FUNG KOREA), Vendor (HANSOLL TEXTILE L...), Factory (HABAC EXPORT GA...), Adopted Style Handoff (12/01/2020), PP Deadline (01/08/2021), UM (IN), POM Page Description (JRSY.65/35 POLY/RYN.VIETNAM (HABAC)), Created On (2020-12-07 22:23:30), Modified on (2021-02-10 15:02:10), and Fit Workflow Alert (38).
- Sample Information:** Fit Sample (Sample 2), Sample Type (PRE-PRODUCTION SA...), and Fit Status (APPROVED).
- Additional Fields:** Date Received (01/08/2021), Ownership (CTD), Decision Date (01/08/2021), Measurer 1 (CYNTHIA KIM), Measurer 2, Actual Fabric/Material (Yes), Actual Trim/Hardware (Yes), Block/Last Used (--Select--), Actual Outsole (--Select--), Date Fit (01/08/2021), and Fit With.

2. The Fit Eval page will be renamed in the POM page description field to include the factory name, following the POM NAMING CONVENTION.

This screenshot shows the 'Fit Evaluation' form with a red box around the 'POM Page Description' field, which contains the text 'JRSY.65/35 POLY/RYN.VIETNAM (HABAC)'. A red arrow points to this field, indicating that the description should be updated to include the factory name.

3. A Counter sample should **ALWAYS** be the first sample in each Fit Eval. The user should add a “Counter Sample” under Sample 1, and select the Fit Status “Approved.” Once this step is complete the user can create a “PP Sample” round under “Sample 2” for the additional factory.

Sample Selection

Fit Sample	Size	Sample #	Sample Type	Fit Status
All	9			
Sample 2	9	1130973	PRE-PRODUCTION SAMPLE	APPROVED
Sample 1	9		COUNTER SAMPLE	APPROVED

