


CHAIR

HOW TO MEASURE MANUAL

1/23/2020

KOHL'S

Kohl's How to Measure Manual - Chairs



406-02

Chair - Heights

406-02A: Total Height

Measure from the floor to the highest point of the chair.

406-02B: Seat Height

Measure from the floor to the top of seat at center front. (If chair comes with a cushion, use a flat edge to measure seat height with cushion)


406-02C: Front/Back Support Bar Height

Measure from floor to the bottom of support bar at center front/center back.

406-02D: Side Support Bar Height

Measure from floor to the bottom of support bar at center sides.

Kohl's How to Measure Manual - Chairs



406-04

Chair - Seat and Leg Span

406-04A: Seat Width

Measure from edge to edge in center of seat. If seat is not uniform in shape, measure at front and back width.

406-04B: Seat Depth

Measure from back edge of seat to front edge of seat at center.


406-04C: Front/Back Leg Span

Measure straight from outer edge to outer edge at bottom of legs at front and back.

406-04D: Side Leg Span

Measure straight from outer edge to outer edge at bottom of legs at sides.

Kohl's How to Measure Manual - Chairs




406-06 Chair - Back

406-06A: Back Height
Measure from seat to
top edge of back.

406-06B: Back Width at Top
Measure straight from outer edge to outer
edge at top of back.

406-06C: Back Width at Bottom
Measure straight from outer edge to outer
edge at bottom of back.

Kohl's How to Measure Manual - Chairs




406-08 Chair - Depth

406-08A: Total Depth
Measure from front edge of chair to back edge of chair.

406-08B: Total Arm Height
Measure from floor to the highest point on arm.

406-08C: Arm Depth
Measure from back edge of arm to front edge of arm.
(If curved, measure with curve)

Kohl's How to Measure Manual - Chairs



406-10 Chair - Arms


406-10A: Arm Span

Measure from outer edge of arm to outer edge of arm across chair at the widest point.

406-10B: Arm Width

Measure from outer edge of arm to outer edge of arm at the widest point.

Kohl's How to Measure Manual - Chairs




406-12 Chair - Rocker

406-12A: Runner Length Straight
Measure straight from back edge to front edge of runner.

406-12B: Runner Length w/ Curve
Measure from back edge to front edge of runner along top, with curve.

406-12C: Runner Placement Front
Measure from front edge of leg to front edge of runner.

406-12D: Runner Placement Back
Measure from back edge of leg to back edge of runner.



BACK ROCKER PLACEMENT

FRONT ROCKER PLACEMENT